

HS2100 / HS3100



EMC Configuration and Accessories Guide

Designed to assist customers and partners with model and configuration guidance



HS2100 / HS3100

CONFIGURATION & ACCESSORY GUIDES are available on <u>The Source</u> and <u>PartnerCentral</u>

Also see

https://www.zebra.com/us/en/product s/mobile-computers/wearablecomputers/hs3100-hs2100.html and the HS2100 / HS3100 Configuration and Accessories Guide

Find Product Information in the EMC Product Portfolio on The Source

and PartnerCentral





HS2100 / HS3100 Configuration Matrix

CONFIGURATION OPTIONS:	DESCRIPTION
HS2100-OTH	HS2100 Rugged Wired Headset Over-The-Head Headband Includes HS2100 Boom Module and HSX100 OTH Headband Module
HS2100-BTN-L	HS2100 Rugged Wired Headset Behind-The-Neck Headband Left Includes HS2100 Boom Module and HSX100 OTH Headband Module
HS3100-OTH	HS3100 Rugged Bluetooth Headset Over-The-Head Headband Includes HS3100 Boom Module and HSX100 OTH Headband Module
HS3100-BTN-L	HS3100 Rugged Bluetooth Headset Behind-The-Neck Headband Left Includes HS3100 Boom Module and HSX100 BTN Left Headband Module



Headset Models



HS2100 Corded Headset



HS3100 Bluetooth Headset

HS2100 / HS3100

- HD Voice Brings Incredible Audio Clarity to cordless and corded models
- · Built to handle the everyday inevitable drops
- Dust-proof, Spray-proof and Waterproof
- Ready for the Freezer and Outdoor Subzero Temperatures
- Feather-light for extraordinary comfort
- Noise cancellation for a superior voice experience in the noisiest environments
- Swap batteries on the fly without losing the Bluetooth connection
- Customizable wearing styles
- · Split-second tap-to-pair simplicity
- Detachable swivel boom minimizes costs
- User-replaceable ear pads and mic windscreens maximize comfort and hygiene
- 15 hours of battery power for cordless models
- Microphone Mute

HS2100 HS3100 Accessories Guide





HS2100 / HS3100 Modules

Boom Modules



HS3100-BOOM-01

HS3100 Boom Module Includes microphone boom, battery, and Windscreen



HS2100-BOOM-01

HS2100 Boom Module Includes microphone boom and Windscreen

Headband Modules



KT-HSX100-OTH1-10

HS2100 and HS3100 Over-The-Head Headband only, Pack of 10. Does not include T-Pad, Ear Cushion, or Boom Module

HSX100-OTH-HB-01

HS2100 and HS3100 Over-The-Head headband including Foam Pad, T-Bar with pad. Does not include Boom Module.

KT-HSX100-BTNL1-10

HS2100 and HS3100 Behind-The-Neck Headband left only, Pack of 10. Does not include T-Pad, Ear Cushion, or Boom Module

HSX100-BTN-L-HB-01

HS2100 and HS3100 Behind-The-Neck Headband left and Foam Ear Pad. Does not include T-Pad or Boom Module.



HS3100 8 Slot Battery Toaster



SAC-HS3100-B8-01

Includes: HS3100 8-slot Battery Charger Requires: Level VI Power Supply PWR-BGA12V50W0WW, DC Line Cord CBL-DC-388A1-01, and country specific line cord

Additional Accessories for Battery Toaster



PWR-BGA12V50W0WW

Level VI AC/DC Power Supply (Brick, replacement for PWRS-14000-148R) **AC Input:** 100-240V, 2.4A **DC Output:** 12V, 4.16A, 50W **Requires:** DC line cord and Country specific grounded AC line cord.



CBL-DC-388A1-01

DC Line Cord for running the single slot cradles or battery chargers from a single Level VI power supply PWR-BGA12V50W0WW, Level VI replacement for PWRS-14000-148R.



23844-00-00R

US AC line cord, 7.5 feet long, grounded, three wire for power supplies.



HS3100 Battery Toaster with 8 Slot WT6000



SAC-HS3100-B8W8-01

Includes: HS3100 8-slot Battery Charger and 8-slot WT6000 charger Requires: Level VI Power Supply PWR-BGA12V108W0WW, DC Line Cord CBL-DC-381A1-01, and country specific line cord

Additional Accessories for Battery Toaster with WT6000



PWR-BGA12V108W0WW

Level VI AC/DC Power Supply (Brick, Replacement for PWRS-14000-241R) **AC Input:** 100-240V, 2.8A **DC Output:** 12V, 9A, 108W <u>Requires:</u> DC line cord and Country specific grounded AC line cord.



CBL-DC-381A1-01

DC Line Cord for running multi-slot cradles from a single Level VI power supply PWR-BGA12V108W0WW



23844-00-00R

US AC line cord, 7.5 feet long, grounded, three wire for power supplies.



HS3100 Battery / Charge Cable

Spare Battery



BTRY-HS3100-HS1-01 Single HS3100 Battery

BTRY-HS3100-HS1-08 Single HS3100 Battery, 8 pack

Charge / Communication Cable



CBL-HS3100-CUC1-01

HS3100 Charging and Communication cable, USB Type-A



HS2100 Cables

Headset Adapter Cables



CBL-HS2100-QDC1-01 Quick Disconnect (QD) Cable for HS2100 Headset



25-114186-03R

WT41N0 headset adapter cable with a coiled section, Requires CBL-HS2100-QDC1-01 to connect to HS2100 headset



CBL-HS2100-12S1-01 HS2100 headset cable to connect directly to WT6000



25-129940-02R

WT41N0 headset short adapter cable (4") for wrist mounted, Requires CBL-HS2100-QDC1-01 to connect to HS2100 headset



CBI -HS2100-3MS1-01 HS2100 headset cable to connect directly to TC7X and TC8000



25-124412-02R

WT41N0 headset long adapter cable (19") for hip mounted, Requires CBL-HS2100-QDC1-01 to connect to HS2100 headset

CBL-NGWT-AUQDLG-01

WT6000 headset long adapter cable for hip mounted, Requires CBL-HS2100-QDC1-01 to connect to HS2100 headset

CBL-NGWT-AUQDST-01

WT6000 headset short adapter cable for wrist mounted, Requires CBL-HS2100-QDC1-01 to connect to HS2100 headset





25-124411-03R

MC31 / MC32 headset adapter cable, Requires CBL-HS2100-QDC1-01 to connect to HS2100 headset





HS2100 / HS3100 Consumables

Consumables



KT-HSX100-TBP1-20 HSX100 Headset Series T-Bar with Pad, Pack of 20



KT-HSX100-EPL1-20 HSX100 Headset Leatherette Ear Pad, Pack of 20



KT-HSX100-EPF1-20 HSX100 Headset Foam Ear Pad, Pack of 20



KT-HSX100-MWS1-50 HSX100 Headset Series Microphone Windscreen, Pack of 50



KT-HS2100-CC1-20 HS2100 Headset Series Microphone Cord Clip, Pack of 20